

Top Mount Refrigerator— Technical Information

**ATB1821AR*, ATB1830AR*, ATB1836AR*, ATB1838AE*, ATB1832AR* CTB1821AR*,
MTB1891AR*, MTB1893AR*, MTB1895AE***

Due to a possibility of personal injury or property damage, always contact an authorized technician for service or repair of this refrigerator.



CAUTION

All safety information must be followed as provided in Service Manual 16023446



WARNING

To avoid risk of electrical shock that can cause death or severe personal injury, disconnect unit from power before servicing unless testing is required. Discharge capacitors through a 10,000 ohm resistor before handling. Wires removed during disassembly must be replaced on correct terminals to ensure proper grounding and polarization.

No-Load Performance, Controls in Normal Position													
	Kw/24 hr ± 0.4			Percent Run Time $\pm 10\%$			Cycles/24 hr $\pm 25\%$			Refrigerator Center Compartment Average Food Temperature $\pm 3^\circ\text{F}$		Freezer Compartment Average Food Temperature $\pm 3^\circ\text{F}$	
Ambient $^\circ\text{F}$	65°	90°	110°	65°	90°	110°	65°	90°	110°	65°	90°	110°	
18 cu ft	0.8	1.2	2.2	26	45	70	31	24	20	37	36	36	

Temperature Relationship Test Chart							
	Evaporator Outlet $\pm 3^\circ\text{F}$	Evaporator Inlet $\pm 3^\circ\text{F}$	Suction Line $\pm 7^\circ\text{F}$	Average Total Wattage $\pm 10\%$	Suction Pressure $\pm 2\text{ PSIG}$	Head Pressure $\pm 5\text{ PSIG}$	
Ambient $^\circ\text{F}$	65°	90°	65°	90°	65°	90°	65°
18 cu ft	-15	-14	-15	-14	65	95	135

Component Specifications



WARNING

To avoid risk of electrical shock that can cause death or severe personal injury, disconnect unit from power before servicing unless tests require power. Discharge capacitors through a 10,000-ohm resistor before handling. Wires removed during disassembly must be replaced on correct terminals to ensure proper grounding and polarization.

Component	Specifications all parts 115VAC/60HZ unless noted	
Compressor run capacitor	Volt.....	220 VAC
	Capacitance	14 μ fd \pm 10%
Compressor	BTUH	595 BTUH
	Watt	60 Hz / 134 watts
	Current Full load	15.3 amps \pm 15% 1.19 amps \pm 15% 3.682 ohms \pm 15% 7.628 ohms \pm 15%
FF Temperature control	Settings #1 – out..... #4 – Differential..... #4 – out..... #7 – out.....	Temperatures 23.1°F \pm 3° 51°F \pm 1.5° 17.9°F \pm 1.5° 16.1°F \pm 3°
Condenser motor	Rotation (facing end opposite shaft) RPM..... Watt	Clockwise 1250 RPM 8.0 watts \pm 13% @ 115VAC 0.10 amps \pm 15% @ 115VAC
Evaporator fan motor	Rotation (facing end opposite shaft) RPM..... Watt.....	Counter-Clockwise 2700 RPM 6.5 \pm 13% watts @ 115VAC
Overload/Relay	Ult. trip amps @ 158°F (70°C)..... Close temperature	2.61 amps \pm 15% 156°F \pm 6°
	Open temperature.....	266°F \pm 3°
	Short time trip (seconds).....	10 seconds \pm 5
	Short time trip (amps @ 77°F (25°C)..	14 amps \pm 2amps
Thermostat (Defrost)	Volt	120/240 VAC
	Current.....	10/2.5 amps
	Resistance across terminals: Above 61.1°F \pm 5°..... Below 22.2°F \pm 7°	Open Closed
Evaporator heater	Volt	115 VAC
	Wattage	395 \pm 5% watts @ 115VAC
	Resistance.....	33.4 \pm 5% ohms
Defrost timer	Volt	120VAC, 60 HZ
	Defrost period (minutes).....	21 \pm 3
	Defrost cycle (hours).....	10
Light switch	Type.....	SPST NC
	Volt.....	125/250 VAC
	Current.....	8 / 4 amps

Wiring Diagram



WARNING

To avoid risk of electrical shock that can cause death or severe personal injury, disconnect unit from power before servicing unless tests require power. Discharge capacitors through a 10,000-ohm resistor before handling. Wires removed during disassembly must be replaced on correct terminals to ensure proper grounding and polarization.

