GE APPLIANCES
a Haier company

Part Install Instructions

Applicable To The Following TO9 Oven Controls:
WB27X45466

IMPORTANT SAFETY NOTICE

The information in this part instruction is intended for use by individuals possessing adequate backgrounds of electrical, electronic and mechanical experience. Any attempt to repair a major appliance may result in personal injury and property damage. The manufacturer or seller cannot be responsible for the interpretation of this information, nor can it assume any liability in connection with its use.

WARNING

To avoid personal injury, disconnect power before servicing this appliance. If electrical power is required for diagnosis or test purposes, disconnect the power immediately after performing the necessary checks. **RECONNECT ALL GROUNDING DEVICES.** If grounding wires, screws, straps, clips, nuts, or washers used to complete a path to ground are removed for service, they must be returned to their original position and properly fastened.

Parts Included:

- Control Board

Overview: This service control is programable to replace multiple different service parts and may look different from the control on the range. It must be programmed before use.

If control personality has previously **been set**, verify personality setting is correct by simultaneously press **START** and **UP** for 2 seconds, within 5 minutes of power up, to display the current personality. If personality is correct, press the **CLEAR/OFF** key to exit personality setup, but if the personality is incorrect, then proceed to (step 1).

If control personality has **never been set**, the control will enter set mode when powered up.

1. Find the original range control number on the parts catalog and match it to the table on the back of this sheet.

2. Select the personality setting using the **UP** and **DOWN** keys until the desired personality number appears in the display. If unable to locate personality setting number on the display, the wrong control may have been ordered or shipped.

3. To set the personality, press and hold the **START** key for 2 seconds. The control will reboot with the selected personality setting.

- The new control has both a white (P100) and a red (P200) connector on this board, refer to the previous control on the range and use the connector which fits the harness.

Original Control Part Number From Parts Catalog	Personality Setting
WB18X20153	32
WB27K10096	5
WB27K10097	6
WB27K10098	7
WB27K10152	8
WB27K10153	9
WB27K10154	10
WB27K10201	5
WB27K10202	6
WB27K10203	7
WB27K10204	8
WB27K10205	9
WB27K10206	10
WB27K10211	5
WB27K10212	6
WB27K10213	7
WB27K10214	8
WB27K10215	9
WB27K10216	10
WB27K10340	12
WB27K10341	11
WB27K10342	10
WB27K10343	9
WB27K10344	8
WB27K10345	7
WB27K10346	6
WB27K10347	5
WB27K10348	24
WB27K10357	5
WB27K10358	6
WB27K10359	7
WB27K10360	8
WB27K10361	9

Original Control Part Number From Parts Catalog	Personality Setting
WB27K10362	10
WB27K10363	11
WB27K10364	12
WB27K10366	24
WB27T10467	15
WB27T10468	16
WB27T10489	13
WB27T10519	14
WB27T10604	17
WB27T10816	15
WB27T10817	16
WB27T10818	17
WB27T10830	18
WB27T11153	19
WB27T11154	20
WB27T11165	21
WB27T11166	22
WB27T11250	23
WB27T11271	13
WB27T11272	14
WB27T11273	15
WB27T11274	16
WB27T11275	17
WB27T11278	19
WB27T11279	20
WB27T11280	21
WB27T11281	22
WB27T11282	23
WB27T11309	13
WB27T11310	14
WB27T11311	15
WB27T11312	16
WB27T11313	17

Original Control Part Number From Parts Catalog	Personality Setting
WB27T11349	26
WB27T11350	27
WB27T11415	29
WB27T11447	18
WB27T11485	31
WB27T11486	32
WB27T11487	34
WB27T11488	35
WB27T11501	33
WB27X20078	35
WB27X20230	140
WB27X20263	145
WB27X22668	143
WB27X22940	144
WB27X23307	145
WB27X23560	146
WB27X26140	149
WB27X26540	153
WB27X26760	163
WB27X26761	164
WB27X29085	140
WB27X29086	145
WB27X29087	14
WB27X29088	149
WB27X29089	153
WB27X29090	13
WB27X29091	32
WB27X29092	164
WB27X29093	163
WB27X29137	8
WB27X37105	32
WB27X37226	164
WB27X37285	163
WB27X37428	153