Electrolux

SERVICE FLASH

RF1605

11.01.16

French-Door Fill Tube Freezing for Freezer Ice Maker

BRAND **Electrolux, Frigidaire, Crosley, Viking.**

MODEL **French Door Bottom Mount Refrigerators.**

SERIAL # **4A432xxxxx to to 4A718xxxxx**

CONDITION **The fill tube for the freezer ice maker is freezing, stoping the ice production.**

SOLUTION Remove crisper/deli bin located at the bottom of the fresh food section and inspect the freezer ice maker fill tube.
If it does not contain the insulator; order and install Fill Tube Insulator Kit (**5303918762**). This contains:







