


Drive motor does not turn.

Note: Always check wiring to the components.



NOTE: If the drive motor windings check open or shorted check the fuse on the speed control board. If the fuse is open, replace the motor and speed control board.

