

Operational Fuse

A non re-settable 10 amp fuse is in the neutral side line this shuts down the inverter / motor

Shorted brake resistor or motor problem can cause fuse failure.

Bending the harness can cause damage.

