

LNTT2516

Dryer Door Rattling

06.13.25

BRAND: Electrolux

MODEL: ELFE7637AT ELFE7537AT ELFE7337AW ELFE7437AW ELFG7637AT ELFG7537AT
ELFG7337AW ELFG7437AW ELTE7600AT ELTE7600AW ELTE760CAT ELTE760CAW
ELTE730CAW ELTG7600AT ELTG7600AW ELTG7300AW ELTE7300AW

SERIAL: All

CONDITION: Dryer door rattling during operation.

SOLUTION: Please select the Play Button below to watch a demonstration of the recommended repair being completed.



For Additional Questions Please Contact The Electrolux Technical Support Team: 1-888-842-3660