



The diagram shows the wiring for the potentiometer and momentary switch. The potentiometer has terminals 1, 1a, and 47. The momentary switch (rotary) has terminals 1, 2, and 1a. The wiring is as follows:

- POTENTIOMETER terminal 1 is connected to terminal 41 of the MOMENTARY SWITCH.
- POTENTIOMETER terminal 1a is connected to terminal 42 of the MOMENTARY SWITCH.
- POTENTIOMETER terminal 47 is connected to terminal 1a of the MOMENTARY SWITCH.
- Terminal 18 BL 12 is connected to terminal 1 of the POTENTIOMETER.
- Terminal 18 BR 12 is connected to terminal 1a of the POTENTIOMETER.
- Terminal 18 BK 12 is connected to terminal 47 of the POTENTIOMETER.
- Terminal 18 Q 12 is connected to terminal 1 of the POTENTIOMETER.
- Terminal 18 Y 12 is connected to terminal 1a of the POTENTIOMETER.
- Terminal 18 W 12 is connected to terminal 47 of the POTENTIOMETER.



