

GE Consumer & Industrial

Service Bulletin

JULY 2010

LAUNDRY

HL02-10

MODELS: DLSR483EG/GG, DWSR483EG/GG,
DWXR483EG/GG, DBSR463EG/GG,
DBXR463EG/GG, DJXR433EG/GG

Customer Issue

Rotary start switch is loose or has fallen off control panel on models produced between **January and May 2010** (serial numbers **AT - HT**).

GE Consumer & Industrial

Service Bulletin

JULY 2010

LAUNDRY HL02-10


MODELS: DLSR483EG/GG, DWSR483EG/GG,
DWXR483EG/GG, DBSR463EG/GG,
DBXR463EG/GG, DJXR433EG/GG

Customer Issue

Rotary start switch is loose or has fallen off control panel on models produced between January and May 2010 (serial numbers AT - HT).

Important:

When replacing the control panel due to a broken switch mounting tab on models produced between January and May 2010, DO NOT reinstall the old switch on the new control panel. You **MUST** replace the start switch at the same time as the control panel or the issue may reoccur.



Start switch and control panel example



GE Appliances
General Electric Company
Louisville, Kentucky 40225

GE CONFIDENTIAL AND PROPRIETARY INFORMATION NOT FOR PUBLIC DISCLOSURE

07/16/10

GE HL02-10




imagination at work

Copyright 2010

Important:

When replacing the control panel due to a broken switch mounting tab on models produced between January and May 2010, DO NOT reinstall the old switch on the new control panel. You **MUST** replace the start switch at the same time as the control panel or the issue may reoccur.



Start switch and control panel example

