


FOR SERVICE TECHNICIAN'S USE ONLY


Wiring Diagram

NOTE:

- End of line tester (EOL) is for manufacturing purposes only.
- Dots indicate connections or splices.
- Circuit shown in Standby/Off mode with oven door closed.
- All voltages in the wiring diagrams are designated as 120/240 VAC. If oven is connected to 120/208 VAC, replace 240 VAC with 208 VAC.
- Pigtail connector pin assignment are located in the tech sheet.



LEGEND




À L'USAGE DU TECHNICIEN DE MAINTENANCE SEULEMENT

Schéma de câblage

REMARQUE :

- Le testeur de bout de ligne ne sert qu'à la fabrication.
- Les points indiquent des connexions ou des épissures.
- Circuit illustré en mode Standby/Off (veille/arrêt) avec la porte du four fermée.
- Toutes les tensions des schémas de câblage ont pour valeur 120/240 V CA. Si le four est connecté à 120/208 V CA, remplacer 240 V CA par 208 V CA.
- Les fonctions des broches du connecteur du raccord flexible sont indiquées dans la fiche technique.



LÉGENDE

